


70.0mm

115.0mm



**FENIX 2.0**  
Herb Vaporizer


**USER MANUAL**

**Thank you for purchasing the Fenix 2.0 vaporizer!**

In order to ensure safe use, please read all instructions and safety warnings before operating. Failure to follow instructions may result in injury and may void your warranty.


**Key Features**

- Air Heating
- Stainless Steel Air Path
- 4400mAh Battery
- Removable & Titanium Chamber
- 3-7 Minutes Working Time Adjustable



1


**Fenix 2.0 Vaporizer Overview**



- Mouthpiece
- Power Button
- Display
- Control Button +
- Control Button -

2

**Includes**



- Clean Brush
- Packing Tool
- USB Cable
- Chamber Removing Tool
- Titanium Chamber
- Cleansing Wipe

3

**Important Usage Tips**




- Rapidly press power button **5 times** On/Off with Vibration feedback.
- Press and hold power button and "-" button simultaneously within **2 seconds** to change from Fahrenheit to Celsius degrees or from Celsius to Fahrenheit.
- Working time setting, hold power button in **2 seconds** until cursor position under SET of timer, press control button +/- to adjust working time from 180 to 240 seconds.
- 320-430°F** Temperature reached with Vibration Feedback.
- Display indicates temperature information, battery status, duration timer.
- Quick battery check : one hit on power button when device is off , the icon on screen will show remain battery level.

4

70.0mm

115.0mm


**How To Load With Dry Herb**

-  Remove mouthpiece from the device.
-  Load choice dry herb loosely into titanium heating chamber. Do not over-fill.
-  Attach the mouthpiece back to device.


5

**Display Indication**


**Fahrenheit Display**  
Temperature Display Default to Fahrenheit, cursor position at SET, can +/- temperature



**Celsius Display**  
Celsius Temperature Display, cursor position at SET, can +/- temperature




**Timer Display**  
Working time setting display, cursor position at SET can adjust time




6

**How To Remove Heating Chamber**



- Insert chamber remove tool into grooves, rotating 90° to remove chamber from device.
- Warning: Please do not remove the chamber after immediate use, parts can get hot.




- After clean, insert the chamber and holder into device, use chamber remove tool to lock the chamber tightly.


7

**Load/RemoveThe Mouthpiece Components**

- When load or remove mouthpiece components, please open the mouthpiece firstly .



**Mouthpiece Open**      **Mouthpiece Close**




- Place mouthpiece components and device at 25° angle, insert into device. Press downward as shown.

- When remove follow above steps in reverse.

8

**Charging Instructions**

- Battery capacity **4400 mAh**, regular USB charging, micro **5V/2A** suggested.
- Initially charge the Fenix 2.0 for **3 hours**.The battery will stop charging when the icon is full.
- When battery level is low, charge battery with included micro USB cable to compatible wall charger. Low battery level will be indicated with icon .
- Do not use Fenix 2.0 while charging.



9



[MagicVaporizers](#) – Europe's Best Shop for Vaporizers

- Lowest prices
- Fastest shipping
- Most trusted warranty

